

Introducing BluKey PayStation™ XL



BluKey PayStation XL



Installation Guide

BluKey PayStation XL


Welcome to your new BluKey PayStation XL. PayStation, our connected room solution, enables your customers to conveniently use any PayRange enabled machine nearby, without the need for a phone or PayRange account. The BluKey PayStation XL streamlines the entire payment process, allowing users to complete their transactions directly on the PayStation.

Use this guide to install your new BluKey PayStation XL. We designed setup to be completed within 30 minutes with intuitive, simple packaging and easy-to-follow instructions.

Before Getting Started

- ✓ Make certain your machines are equipped with a PayRange BluKey.
- ✓ Make sure there is a stable and adequate internet connection in the room you will be installing the PayStation.
- ✓ Ensure a 110V outlet is available to power the PayStation.

PayRange Laundry System – Products Required



Laundry Machine



BluKey




BluKey Connect



BluKey PayStation XL

What's Required to Get Started

- 1 Smartphone with PayRange App
- 2 PayRange Operator Account
- 3 Tools to assist with installation
- 4 PayRange products (PayStation, BluKey, BluKey Connect)
- 5 PayRange enabled machines
- 6 Stable internet connection & 110V power outlet



Tools Required



Phillips screwdriver



Recommended cordless drill

What's Included

The PayRange BluKey Connect is required for use with the PayStation XL. If you ordered a PayStation XL, the PayRange BluKey Connect will ship separately with your order.



BluKey PayStation XL



Antenna



Back Panel Cover



Power Cord



Drywall Fasteners
Mounting Screws

Getting Started

IMPORTANT: PayRange BluKey PayStation XL service requires data connection. Prior to installation, verify location has adequate cellular reception. If a mobile web browser can load a website relatively quickly, data connection should be adequate.

Prepare PayStation

- 1 Carefully remove the BluKey Connect and BluKey PayStation XL from their packaging.
- 2 Plug in the power cord and antenna to the back of the PayStation XL (Fig. 1).
- 3 If using an internet or cellular connection, connect the ethernet cable from the ethernet router or cellular modem to the ethernet port located on the back of the PayStation (Fig 1).
- 4 Remove the mounting bracket attached to the back of the PayStation by unscrewing the two screws from the bottom sides of the bracket (Fig 1).
- 5 Screw the mounting bracket to the wall using the included mounting hardware (Fig. 2).



Best practice is to **install** the BluKey PayStation next to the laundry room **change machine**.




FIG. 1
(BACK OF PAYSTATION)

Getting Started

6

Plug the power cord into a 110V outlet and power on the PayStation XL by pressing the power switch located next to the power cord. Ensure the PayStation powers ON and the home screen is displayed (Fig 3).

7

Attach the included back panel cover to the back panel window using the two screws provided (Fig. 3).

8

Attach the PayStation XL to the mounting bracket that was previously mounted to the wall in the previous step (Fig. 4).

9

Follow the on-screen instructions for the remaining installation and set-up.




FIG. 2




FIG. 4




FIG. 3

Get the most from PayRange

Resources, education, and support at your fingertips 24/7

PayRange Central

PRODUCT RESOURCES

Find the latest videos for common support scenarios, account setup, installation, and setting up promotions.

Visit vimeo.com/payrange

PayRange Support

SUPPORT

Visit our operator support page to find answers to frequently asked questions. Learn how to set up promotions, register devices and more.

Visit support.payrange.com

Technical Support

 ask@payrange.com

Sales & Marketing

SHOP PAYRANGE

 sales@payrange.com



Need Support?

For assistance with installing and operating your PayRange devices, please contact our support team.