


1

Long tap on the weather widget



2

Enter PIN if needed

Note: PIN can be viewed by tapping on “Show Device Pin” button in the respective Kiosk page on Manage

Enter PIN


— — — —

1	2	3
4	5	6
7	8	9
	0	⌫

Close


3

Tap on View Nodes




4

Tap on Node that needs network




5

Tap on Configure WiFi




6

Select the WiFi network of the Kiosk




7

Enter the WiFi password & Connect



8

Kiosk will connect & configure the node



9

Node will reboot

View Nodes

B8:27:EB:65:57:9A

Rebooting...

>

BLE

3 Devices

>

Close

10

**Node will disappear from the list during
reboot**



11

You will see an IP address upon successful configuration update

Note: Please check the WiFi credentials & re-configure if the IP address doesn't appear

